xiaomi Smart Air Fryer 4.5L User Manual - 1
Xiaomi Smart Hei8luft-Fritteuse 4,5 L Bedienungsanleitung - 12
Manuale utente Xiaomi Smart Air Fryer 4.5L - 23
Manuel d'utilisation de Xiaomi Smart Air Fryer 4.5L - 34
Manual de usuario de la Xiaomi Smart Air Fryer 4.5L - 45
Руководство пользователя аэрогрилю Xiaomi Smart Air Fryer 4.5L - 56
Instrukcja obsługi Wielofunkcyjna frytkownica Xiaomi Smart Air Fryer 4,5 l - 67
دليل المستخدم مقلاة Xiaomi الهوائية الذكية 4.5L - 78
Xiaomi Akıllı Hava Fritözü 4.5L Kullanım Kılavuzu - 89
Nồi chiên không dầu thông minh Xiaomi 4,5L Hướng dẫn sử dụng - 100
Panduan Pengguna Xiaomi Smart Air Fryer 4.5L - 111
Посібник користувача розумної фритюрниці Xiaomi Smart Air Fryer 4.5L - 122
Xiaomi 4,5Л смарт аэрогрилінің пайдаланушы нұсқаулығы - 133

Read this manual carefully before use, and retain it for future reference.
Thank you for choosing Xiaomi Smart Air Fryer 4.5L. This product is for household use only. Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

Safety Instructions

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instructions concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Please keep the air fryer and the power cord out of the reach of children aged under 8.
- For household use only.
- If the power cord is damaged or broken, it must be replaced by the manufacturer or after-sales service department to avoid safety hazards.
- The temperature of the accessible surface may rise while the Xiaomi Smart Air Fryer is working.
- The surface will heat up easily while the air fryer is in use.
- The air fryer should not be operated via an external timer or a separate remote control.
- Do not block the air fryer's air inlet and outlet, nor the heat dissipation vents during use to avoid affecting its normal heat dissipation.
- Any non-professionally trained technicians should not modify the internal wiring of the air fryer.
- Do not use charcoal or other similar fuel sources to heat the basket, frying plate, or grill.
- Do not place the basket or any other heat sources, such as an induction cooker or gas stove.
- Do not plug or unplug the power cord with wet hands to avoid the risk of an electrical shock.
- Do not use a power cord with loose connection or poor contact.
- Do not let the power cord cross through sharp objects to avoid damage to the power cord.

- Do not use the air fryer to store any items, especially flammable, explosive, or corrosive items.
- Do not excessively pinch, bend, twist, or place heavy objects on the power cord to prevent from exposing or breaking its core.
- Stop using the air fryer immediately and unplug it from the power source if it doesn't function normally or malfunctions.
- The air fryer cannot be started without the basket being in place.
- Do not touch the basket directly with your hands during or right after use to avoid getting scalded.
- Do not allow children to get close to or play with the cling wrap and packaging to avoid suffocation accidents.
- Do not use any plastic utensils or normal paper wrapping materials to wrap food for cooking.
- Do not drop this air fryer or bump it against hard objects to avoid damage or malfunction.
- Do not insert pins, wires or other objects into any of the openings of the air fryer to avoid electrical shock or injury.
- Do not use any accessories that are not recommended by the manufacturer.
- The normal operating altitude range of this product is 0–2000 meters.
- Keep a distance of 30 cm or more between the air outlet and other devices during use.
- Do not move or shake the air fryer during use.
- Do not insert any foreign objects into the safety switch to avoid causing any danger.
- When placing the air fryer in a kitchen cabinet, etc., please ensure that it is well ventilated.
- This product must be used on a level, heat-resistant surface to avoid damage to the product or accidents.
- Ensure that the silicone parts of the air fryer do not come into contact with ethanol or solutions that contain more than 50% of alcohol.
- Please ensure that the electrical outlet the air fryer is plugged into is well grounded to avoid an electrical shock or other safety hazards.

- Only use a grounded electrical outlet with a rated current of 10 A to avoid the risk of fire and other potential hazards.

CAUTION: Hot surfaces.

Product Overview

Notes: 1. The silicone rubber on the frying plate is made of high-temperature resistant materials and is used to prevent food residue from adhering to the edges of the frying plate from scratching the coating of the basket and to improve the stability of the frying plate. Do not remove the silicone rubber on the frying plate.
2. Appropriate oil can be used when cooking, but it is not suitable for use on the grill. Please make sure that ingredients do not touch the heating element on the grill.

Control Knob

How to Use

Connect the power cord and press the power button to turn on the air fryer.
Notes: 1. When the air fryer is turned on for the first time, press the power button to enter the language selection screen. Turn the control knob to the desired language. Press the control knob to confirm the selection.
2. When the air fryer is in standby mode, it will automatically enter the screen saver mode. Place the basket or the mesh net on the cooking platform. Press the power button to wake up the screen. The air fryer may emit a small amount of white smoke or an odor while running with an empty basket, which is normal.

Turning on
Connect the power cord and press the power button to turn on the air fryer.

Turning off
Press the power button to turn off the air fryer, regardless of the state it is in.

Setting Wi-Fi

- Resetting Wi-Fi:
Press the control knob to enter "Reset Wi-Fi" while in the "Wi-Fi" screen, then press the control knob to select Yes to reset the Wi-Fi or turn the control knob to select No to abandon resetting the Wi-Fi.
- Enabling/Disabling Wi-Fi:
Press the control knob to enter "Enable/Disable Wi-Fi" while in the "Wi-Fi" screen, then press the control knob to select Yes to enable or disable the Wi-Fi or turn the control knob to select No to abandon the change.

Wi-Fi status indicator

①	②	③
Awaiting fast connection...	Reconnecting after disconnection...	Connected successfully
Wi-Fi indicator blinks rapidly	Wi-Fi indicator blinks slowly	Wi-Fi indicator stays on

④	⑤
Updating...	Aggiornamento...
Wi-Fi indicator blinks slowly	Wi-Fi indicator blinks quickly

Note: If the air fryer does not connect to the Wi-Fi for 30 minutes, the Wi-Fi indicator will turn off.

Updating firmware

During a firmware update via the Mi Home/Xiaomi Home app, the display shows that an update is in progress. Upon completion of the update, the air fryer will restart automatically.
Note: Do not disconnect the power during a firmware update, as this may damage the device. Ensure the air fryer is fully charged or plugged in before starting an update.

Connecting with the Mi Home/Xiaomi Home app

This product works with the Mi Home/Xiaomi Home app*. Control your device with Mi Home/Xiaomi Home app.

- Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or open Mi Home/Xiaomi Home app and tap "+" in the upper right, and then follow the instructions to add your device.
- If Mi Home/Xiaomi Home app is not available in Europe (except for Russia), The name of the app displayed in your device should be taken as the setup.
- If you have trouble adding Mi Home/Xiaomi Home app, please follow the instructions based on the current app version.

Cooking

Preparations

The ingredients can be marinated to taste before cooking.
Note: Do not cook foods containing baking soda (sodium bicarbonate), such as pretzel sticks, to prevent damage to the air fryer's coating.

Start cooking

1. Place the air fryer on a stable, level surface and ensure that there is an circulation around the air fryer.

2. Place the frying plate at the bottom of the air fryer and put the prepared food onto the plate. Avoid overfilling or piling the food beyond the frying plate's rim. This will prevent the food from rattling against the basket without the need to turn over the food.

3. When the basket is completely pushed into the air fryer, turn the control knob to select the appropriate recipe and set the parameters (such as the amount of ingredients, mode, temperature, and cooking time) according to your needs and preferences. Then press the control knob to confirm settings and start cooking.
Notes:
1. Cooking time and temperature (except for yogurt) can be adjusted during the cooking process without affecting the current cooking mode. However, the control knob is confirm the new settings, and the cooking will continue based on these updated parameters.
2. Switch the recipe on the mode screen to the unfolded list while cooking is underway.

4. When the air fryer's basket is pulled out during cooking, the countdown will blink and cooking will pause. Parameter adjustments are not allowed in this state. Placing the basket back into the air fryer will resume cooking. Pulling out the basket for more than 10 seconds will cancel the current cooking.

5. Once the cooking countdown ends, the air fryer will give off a long beep to indicate the completion of cooking. The air fryer will then enter the keep-warm mode and start a 30-minute countdown. If when cooking is completed within the scheduled time, and then enter the keep-warm mode or finish cooking since then.
Notes:
1. The scheduled time must be longer than the cooking time, but less than 24 hours.
2. If the scheduled time is reached while the air fryer is in standby mode, it will be automatically turned on to preheat the cooking platform. Place the ingredients into the basket and start cooking. The preheat time is based on the current ambient temperature and may vary. Do not open the air fryer during preheating.
3. The scheduled function is not supported in yogurt, dried fruit, and dried vegetable.

Other Operations

1. Language settings

- Turn on the air fryer, go to settings, and press the control knob to enter the language selection screen.
- Turn the control knob to the desired language and press it to confirm.

2. Manual mode

- When the air fryer is turned on, press the control knob to enter the manual mode; then turn the control knob to the desired cooking temperature; press the control knob to set the time and turn the control knob to the desired cooking time, and finally press the control knob to start the manual cooking program.

3. Temperature/time adjustment

- The temperature can be adjusted between 40°C and 200°C. The time can be adjusted between 0–24 hours.
- When adjusting temperature or time, turn the control knob to the right to increase the value and to the left to decrease the value. Press the control knob to confirm the new settings, and the cooking will continue based on these updated parameters.
- Press and hold the control knob for 3 seconds to return to the previous menu.

4. Keep-warm function

- The keep-warm function is enabled by default. This function can be enabled or disabled by navigating to settings > thermostat settings and pressing the control knob on the display. A pre-end-of-heat action on the display for 1 second is required to disable the keep-warm mode after the cooking is finished.
- The keep-warm function is set to last for 30 minutes at a temperature of 80°C. If the air fryer's basket is pulled out while this function is enabled, both the function and the timer will pause and resume when the basket is pushed back in. The keep-warm function will automatically turn off when the air fryer is lifted, if the air fryer is not placed back within 1 minute, the function will end, and the air fryer will return to the home screen of the corresponding recipe.
- The keep-warm function automatically activates after the cooking ends. The air fryer will emit a beep every 1 minute to remind you to remove the food. The keep-warm function will stop when the basket is removed or when the air fryer is lifted. However, it will give one extra beep to remind you to remove the food.

5. Keep-warm function

- The keep-warm function is enabled by default. This function can be enabled or disabled by navigating to settings > thermostat settings and pressing the control knob on the display. Pre-disabling the keep-warm function is required before cooking is finished.
- The keep-warm function is set to last for 30 minutes at a temperature of 80°C. If the air fryer's basket is pulled out while this function is enabled, both the function and the timer will pause and resume when the basket is pushed back in. The keep-warm function will automatically turn off when the air fryer is lifted, if the air fryer is not placed back within 1 minute, the function will end, and the air fryer will return to the home screen of the corresponding recipe.
- The keep-warm function automatically activates after the cooking ends. The air fryer will emit a beep every 1 minute to remind you to remove the food. The keep-warm function will stop when the basket is removed or when the air fryer is lifted. However, it will give one extra beep to remind you to remove the food.
- The keep-warm function is not supported in yogurt, vegetables, dried fruit, and dried meat.

6. Pause/cancel cooking

- When the air fryer is in cooking mode, press the control knob to pause cooking. When the cooking is paused, press the control knob to resume cooking. Pulling out the basket or cancelling cooking will cancel the current cooking and return the manual mode screen.
CAUTION: During cooking, the control knob can be turned to adjust the temperature and time parameters. The corresponding cooking will be paused during adjustment. Once the adjustment is completed, press the control knob to confirm the new parameters.

7. Cloud recipe mode

- When a cloud recipe is selected and executed using the Mi Home/Xiaomi Home app, the air fryer will cook automatically according to the recipe. After cooking, the air fryer will enter the keep-warm mode and start a 30-minute countdown.
Notes: 1. To activate cloud recipes, ensure the air fryer is connected to the app and is in the home screen.
2. The air fryer is in the cooking/keep-warm/pause/cancel mode. 3. The air fryer's basket has been pulled out.

8. Error message

- When the air fryer detects an error, the display will show "E1" or "E2", and the air fryer will emit three brief beeps.

Cleaning & Maintenance

Unplug the power cord before cleaning and maintaining the air fryer, and wait for it to cool down to a safe temperature before proceeding. Please remove the basket from the air fryer when cleaning the air fryer.
- Surface of the air fryer:
Use a damp cloth to wipe the surface clean with a dry, soft cloth or a sponge moistened with a cleaning detergent.
- Cavity:
To remove stains from the inside of the air fryer, apply a suitable amount of detergent to a damp cloth or sponge, and wipe the cavity clean. If stains persist, then use a soft sponge moistened with water to wipe away the detergent residue.
- Basket:
Clean the air fryer after each use. The basket of the air fryer is coated, so do not use any steel wool or other abrasive cleaning materials to clean it as they may damage the coating.
- Frying plate:
Use a soft, cotton cloth or sponge moistened with neutral detergent to wipe it clean, then moisten it with water to wipe away the detergent residue.
Note: The frying plate and grill can be separated and placed in the dishwasher for cleaning. The coating of the basket and frying plate is coated with a non-stick coating. Avoid contact with sharp objects and abrasive materials.

Cleaning Precautions

1. After using the air fryer, please unplug the power plug in time. Do not place the air fryer near the edge of the table or other flammable and explosive dangerous goods. Keep the air fryer away from the air flow of the fan to prevent the plug from scorching the surface.
2. Cleaning and maintenance should only be done after the air fryer has cooled down.
3. Do not use any corrosive or abrasive cleaning materials or detergents.
Note: Regular cleaning and maintenance of the air fryer will help to extend its service life.

Troubleshooting

Issue	Possible Causes	Solutions
The air fryer doesn't function.	The air fryer is not connected to a power supply.	Plug the power cord into a grounded electrical outlet.
	The basket is not pushed into place.	Pull out the basket and push it back into place.
Display shows E1.	The sensor has a broken circuit.	Contact the after-sales service team.
Display shows E2.	The sensor has a short circuit.	Contact the after-sales service team.
The fan doesn't rotate.	The fan blade is stuck.	Remove the fan blade and clean it.
	The motor is damaged or other mechanical failures are present.	Contact the after-sales service team.
	Cooking oily ingredients.	Wait until the ingredients are cooled down, then clean the air fryer.
While smoke is coming out.	The air fryer still contains grease residue from the previous cooking session.	Ensure that you clean the air fryer after each cooking session.
Can't insert the basket into the air fryer smoothly.	Too many ingredients are in the basket.	Take some ingredients out.
	The basket is not properly inserted.	Properly insert the basket.
The schedule function doesn't function as requested.	The scheduled time is too short.	The scheduled time should be longer than the cooking time.
	The scheduled time is not saved.	The scheduled time should be saved and carried out by pressing the control knob.
Wi-Fi can't be connected.	The Mi Home/Xiaomi Home app is not the latest version.	Update the Mi Home/Xiaomi Home app to the latest version.
	The Wi-Fi signal is weak.	Move to a location where the signal is strong enough.
Unable to connect the air fryer.	Wi-Fi cannot be connected.	Check whether the Wi-Fi is connected normally or reset the Wi-Fi to reconnect.

Electrical Diagram

Specifications

Name Over-Air Fryer	Capacity: 4.5 L	Color: White
Model: MAF14	Nominal Voltage: 220–240 V~	Rated Power: 1500 W
Rated Power: 1500 W	Rated Voltage: 220–240 V~	Gross Weight: 6.7 kg
Maximum Output Power of the Wi-Fi Module: > 20 dBm	Operating Frequency: 2412–2472 MHz	
Operating Temperature: –10 °C to 40 °C	Package Dimensions: 370 × 295 × 345 mm	
Wireless Connectivity: Wi-Fi 802.11 b/g/n 2.4 GHz		

Limited stocks are available. The illustrations of the product, accessories, and user interface are for reference only. Actual product and functions may vary due to product enhancements.

Manufactured by: Xiaomi Communications Co., Ltd.
Manufactured by: Ningbo Cuisine Electric Appliance Co., Ltd.
Ningbo Hi8 Electric Appliance Co., Ltd.
(Ningbo Hi8 Electric Appliance Co., Ltd. is a subsidiary of Ningbo Cuisine Electric Appliance Co., Ltd.)
Address: No.58, Wei'er Road, Beilun Industrial Zone, Ningbo City, Zhejiang Province, P.R.C.
Date of production: Refer to the product's production date on its nameplate.
Made in China
Manufactured in Vietnam: VT12

All products bearing this symbol are waste electrical and electronic equipment (WEE) as in directive 2012/19/EU which is governed within the European Union. This means that this product must be treated in accordance with this directive regarding recycling or re-use waste equipment to a designated collection point for recycling of waste electrical and electronic equipment. The electrical and electronic equipment within the scope of 2012/19/EU are made with substances or mixtures which may be dangerous to the environment and human health. Please contact the retailer or local authorities for more information about the location as well as terms and conditions of such collection points.

Leggere attentamente il presente manuale prima dell'uso del dispositivo e conservarlo per ogni riferimento futuro.
Grazie per aver scelto Xiaomi Smart Air Fryer 4.5L. Questo prodotto è destinato esclusivamente all'uso domestico.
Le illustrazioni del prodotto, degli accessori e dell'interfaccia utente nel manuale utente sono esclusivamente a scopo di riferimento. Il prodotto effettivo e le relative funzioni possono variare a causa dei miglioramenti apportati al prodotto stesso.

Istruzioni di sicurezza

- L'apparecchio può essere utilizzato da bambini di età superiore agli 8 anni e da persone con capacità mentali, fisiche o sensoriali ridotte oppure da persone prive di esperienza o conoscenza dell'apparecchio, purché siano sorvegliate o siano state istruite sull'utilizzo in sicurezza dell'apparecchio e comprendano i rischi che ne possono derivare. Non consentire ai bambini di giocare con l'apparecchio. Le operazioni di pulizia e manutenzione non devono essere effettuate da bambini, a meno che non abbiano più di 8 anni e non siano sorvegliati.
- Tenere la friggitrice ad aria e il cavo di alimentazione fuori dalla portata dei bambini di età inferiore agli 8 anni.
- Solo per uso domestico.
- Se il cavo di alimentazione è danneggiato o rotto, deve essere sostituito dal produttore o dal reparto assistenza post-vendita per evitare rischi alla sicurezza.
- La temperatura della superficie accessibile può aumentare durante il funzionamento della friggitrice ad aria.
- La superficie si riscalda facilmente durante il funzionamento della friggitrice ad aria.
- La friggitrice ad aria non può essere usata con un timer esterno o un telecomando indipendente.
- Al fine di evitare di influenzare la regolare dissipazione del calore, durante l'uso della friggitrice ad aria, non bloccare la presa e l'uscita d'aria della friggitrice ad aria, né le ventole di dissipazione del calore.
- Il cablaggio interno della friggitrice ad aria non deve essere modificato da qualsiasi tecnico non professionista.
- Non usare carbone o altre fonti di combustibile simili per riscaldare il cestello, la piastra o la griglia.
- Non posizionare il cestello su altre fonti di calore, come ad esempio su un fornello a induzione o su di una stufa a gas.
- Al fine di evitare il rischio di scosse elettriche non inserire o disinserire il cavo di alimentazione con le mani bagnate.

- Non utilizzare un cavo di alimentazione con una connessione allentata o un contatto insufficiente.
- Per evitare danni al cavo di alimentazione, non lasciare che lo stesso attraversi oggetti appuntiti.
- Non utilizzare la friggitrice ad aria per conservare oggetti, specialmente oggetti infiammabili, esplosivi o corrosivi.
- Al fine di evitare di esporre o rompere l'anima del cavo di alimentazione, non stringere eccessivamente, piegare, torcere o mettere oggetti pesanti sul cavo stesso.
- Interrompere immediatamente l'utilizzo della friggitrice ad aria e scollegare dalla fonte di alimentazione se non funziona normalmente o non funziona correttamente.
- La friggitrice ad aria non può essere avviata senza che il cestello sia in posizione.
- Non toccare direttamente il cestello con le mani durante o subito dopo l'uso.
- Per evitare incidenti per soffocamento, non lasciare che i bambini si avvicinino o giochino con la pellicola trasparente e l'imballaggio.
- Non usare utensili di plastica o materiale di carta per avvolgere il cibo per la cottura.
- Non far cadere la friggitrice ad aria e non sbatterla contro oggetti duri per evitare danni o malfunzionamenti.
- Non inserire perni, fili o altri oggetti in nessuna delle aperture della friggitrice ad aria per evitare scosse elettriche o lesioni.
- Non utilizzare accessori non raccomandati dal produttore.
- La gamma di altitudine di funzionamento normale di questo prodotto è 0–2000 metri.
- Durante l'utilizzo, mantenere una distanza di almeno 30 cm tra l'uscita d'aria e altri dispositivi.
- Durante l'utilizzo, non spostare o agitare la friggitrice ad aria.
- Per evitare qualsiasi pericolo, non inserire oggetti estranei nell'interruttore di sicurezza.
- Quando si colloca la friggitrice ad aria in una credenza, ecc., assicurarsi che sia ben ventilata.
- Prima di pulire o riparare la friggitrice ad aria, assicurarsi di scollegare la spina.
- Per evitare danni al prodotto o incidenti, questo prodotto deve essere utilizzato su una superficie piana e resistente al calore.

- Bewegen oder schützen Sie die Heißluft-Fritteuse nicht während des Betriebs.
- Stecken Sie keine Fremdkörper in die Sicherheitsschalter, um eine Gefährdung zu vermeiden.
- Wenn Sie die Heißluft-Fritteuse in einem Küchenschrank usw. aufstellen, achten Sie bitte darauf, dass sie gut belüftet ist.
- Bitte ziehen Sie unbedingt den Stecker der Heißluft-Fritteuse vor der Reinigung oder Reparatur ab.
- Dieses Produkt muss auf einer ebenen, hitzebeständigen Oberfläche verwendet werden, um Schäden am Produkt oder Unfälle zu vermeiden.
- Achten Sie darauf, dass Sie die Silikonteile der Heißluft-Fritteuse nicht mit Ethanol oder Lösungen, die mehr als 50 % Alkohol enthalten, in Kontakt kommen.
- Stellen Sie sicher, dass die Steckdose, an die die Heißluft-Fritteuse angeschlossen ist, gut geerdet ist, um einen Stromschlag oder andere Sicherheitsgefährdungen zu vermeiden.
- Verwenden Sie nur eine geerdete Steckdose mit einer Nennstromstärke von 10 A, um das Risiko von Feuer und anderen potenziellen Gefahren zu vermeiden.

VORSICHT: Heiße Oberflächen.

Produktübersicht

Bedienknopf

Verwendung

Schließen Sie die Stromkabel an und drücken Sie die Ein-/Aus-Taste, um die Heißluft-Fritteuse einzuschalten.
Hinweise: 1. Wenn die Heißluft-Fritteuse zum ersten Mal eingeschaltet wird, drücken Sie die Ein/Aus-Taste, um die Sprachauswahl zu aktivieren. Drehen Sie den Bedienknopf, um die gewünschte Sprache auszuwählen. Drücken Sie den Bedienknopf, um die Auswahl zu bestätigen.
2. Wenn die Heißluft-Fritteuse im Standby-Modus ist, wird sie automatisch den Bildschirmschoner aktivieren. Stellen Sie den Korb oder das Netz auf die Kochplatte. Drücken Sie die Ein/Aus-Taste, um den Bildschirm zu aktivieren. Die Heißluft-Fritteuse kann beim ersten Betrieb mit leerem Korb eine kleine Menge weißer Rauch oder einen Geruch abgeben, was normal ist.

Einschalten
Schließen Sie das Stromkabel an und drücken Sie die Ein-/Aus-Taste, um die Heißluft-Fritteuse einzuschalten.

Ausschalten
Drücken Sie die Ein/Aus-Taste, um die Heißluft-Fritteuse auszuschalten, unabhängig davon, in welchem Zustand sie sich befindet.

WLAN einrichten

1. Zurücksetzen von WLAN:
Drücken Sie den Bedienknopf, um „WLAN zurücksetzen" auszuwählen, während Sie sich im Bildschirm „WLAN" befinden, und drücken Sie dann den Bedienknopf, um Nein auszuwählen, um das WLAN zurückzusetzen, oder drehen Sie den Bedienknopf, um Nein auszuwählen, um das Zurücksetzen des WLAN zu verlassen.
2. Aktivieren/Deaktivieren des WLAN:
Drücken Sie den Bedienknopf, um „WLAN aktivieren/deaktivieren" auszuwählen, während Sie sich im Bildschirm „WLAN" befinden, und drücken Sie dann den Bedienknopf, um Ja auszuwählen, um das WLAN zu aktivieren/deaktivieren, oder drehen Sie den Bedienknopf, um Nein auszuwählen, um den Vorgang abzubrechen.

WLAN-Status Kontrollleuchte

①	②	③
Verbindung wird schnell hergestellt...	Wiederverbindung nach einer Trennung...	Verbindung erfolgreich hergestellt
WLAN-Kontrollleuchte blinkt schnell	WLAN-Kontrollleuchte blinkt langsam	WLAN-Kontrollleuchte leuchtet dauerhaft

④	⑤
Updates werden installiert...	Aktualisierung wird durchgeführt...
WLAN-Kontrollleuchte blinkt langsam	WLAN-Kontrollleuchte blinkt schnell

Hinweis: Wenn die Heißluft-Fritteuse nach 30 Minuten nicht mit dem WLAN verbunden ist, schaltet die WLAN-Kontrollleuchte sich aus.

Firmware wird aktualisiert

Während einer Firmware-Aktualisierung über die Mi Home/Xiaomi Home App zeigt das Display an, dass eine Aktualisierung läuft. Nach Abschluss der Aktualisierung startet die Heißluft-Fritteuse automatisch neu gestartet.
Hinweis: Trennen Sie während einer Firmware-Aktualisierung das Gerät nicht vom Netz, da dies das Gerät beschädigen kann. Stellen Sie sicher, dass die Heißluft-Fritteuse vollständig aufgeladen ist oder an eine Stromquelle angeschlossen ist, bevor Sie eine Aktualisierung durchführen.

Verbinden mit der Mi Home/Xiaomi Home App

Dieses Produkt funktioniert mit der Mi Home/Xiaomi Home App*. Steuern Sie Ihr Gerät mit der Mi Home/Xiaomi Home App.

- Scannen Sie den QR-Code, um die App herunterzuladen und zu installieren. Sie werden zur Verbindungseinrichtungsseite weitergeleitet, wenn die App bereits installiert ist. Oder öffnen Sie die Mi Home/Xiaomi Home App und tippen oben rechts auf „+", um Ihr Gerät hinzuzufügen.
- Wenn die Mi Home/Xiaomi Home App in Europa (außer Russland) nicht verfügbar ist, wird der Name der App, die auf Ihrem Gerät angezeigt wird, als Einrichtung angezeigt.
- Wenn Sie Probleme beim Hinzufügen der Mi Home/Xiaomi Home App haben, befolgen Sie die Anweisungen entsprechend der aktuellen App-Version.

Garen

Zubereitungen

Die Zutaten können vor dem Garen nach Belieben mariniert werden.
Hinweis: Backen Sie keine Lebensmittel, die Backnatron (Natriumbicarbonat) enthalten, wie z. B. Laugenbrezeln, um die Beschichtung der Heißluft-Fritteuse nicht zu beschädigen.

Garen starten

1. Stellen Sie die Heißluft-Fritteuse auf eine ebene, ebene Fläche und stellen Sie sicher, dass eine Luftzirkulation um die Heißluft-Fritteuse besteht.

2. Legen Sie die Frittierplatte auf den Boden der Heißluft-Fritteuse und geben Sie die vorbereiteten Zutaten auf die Platte. Füllen Sie die Platte nicht zu stark oder stapeln Sie die Frittierplatte höher als bis zum Rand der Platte. Dies verhindert, dass die Zutaten ohne Bedarf an Umdrehen gegen den Korb klappern.

3. Wenn der Korb vollständig in die Heißluft-Fritteuse geschoben ist, drehen Sie den Bedienknopf, um die Zutaten auszuwählen und die Parameter (z. B. Menge der Zutaten, Modus, Temperatur und Garzeit) entsprechend einzustellen. Drücken Sie dann den Bedienknopf, um die Einstellungen zu bestätigen und den Garvorgang zu starten.
Hinweis:
1. Die Garzeit und die Temperatur (außer bei Joghurt) können während des Garvorgangs angepasst werden, ohne dass der aktuelle Garmodus beeinflusst wird. Der Bedienknopf bestätigt die neuen Einstellungen, und der Garvorgang wird auf der Grundlage dieser aktualisierten Parameter fortgesetzt.
2. Wenn der Korb auf dem Modus-Screen während des Garens geöffnet wird, wechseln Sie zum ausgeklappten Bildschirm.

4. Wenn der Korb der Heißluft-Fritteuse während des Garens herausgezogen wird, blinkt der Countdown und das Garen wird unterbrochen. Parameteranpassungen sind in diesem Zustand nicht erlaubt. Das Zurücksetzen des Korbes erlaubt die Wiederaufnahme des Garens. Wenn der Korb mehr als 10 Sekunden herausgezogen wird, wird das aktuelle Garen abgebrochen.

5. Nach Ablauf des Countdowns gibt die Heißluft-Fritteuse einen langen Signalton ab, um anzuzeigen, dass der Garvorgang beendet ist. Nehmen Sie den Korb vorsichtig heraus und entfernen Sie die Zutaten. Die Heißluft-Fritteuse wird dann in den Warmhaltemodus und einen 30-Minuten-Countdown gestartet. Wenn Sie das Gerät innerhalb des geplanten Zeitraums fertig garen oder nach dem Garen das Gerät ausschalten oder vom Netz trennen, wird der Warmhaltemodus beendet und der Countdown wird gestoppt.
Hinweis:
1. Die geplante Zeit muss länger als die Garzeit sein, aber weniger als 24 Stunden.
2. Wenn die geplante Zeit erreicht wird, während die Heißluft-Fritteuse im Standby-Modus ist, wird sie automatisch eingeschaltet, um die Kochplatte vorzuheizen. Legen Sie die Zutaten in den Korb und beginnen Sie mit dem Garen. Die Vorheizzeit basiert auf der aktuellen Umgebungstemperatur und kann variieren. Öffnen Sie die Heißluft-Fritteuse während des Vorheizens nicht.
3. Die geplante Funktion wird bei Joghurt, getrocknetem Obst und getrocknetem Gemüse nicht unterstützt.

Andere Vorgänge

1. Spracheinstellungen

- Schalten Sie die Heißluft-Fritteuse ein, gehen Sie zu Einstellungen und drücken Sie den Bedienknopf, um den Bildschirm zur Sprachauswahl zu öffnen.
- Drehen Sie den Bedienknopf auf die gewünschte Sprache und drücken Sie zur Bestätigung.

2. Manueller Modus

- Wenn die Heißluft-Fritteuse eingeschaltet ist, drücken Sie den Bedienknopf, um in den manuellen Modus einzutreten, drehen Sie dann den Bedienknopf, um die gewünschte Gartemperatur einzustellen, drücken Sie den Bedienknopf, um die Zeit einzustellen und drehen Sie den Bedienknopf, um die gewünschte Garzeit einzustellen, und drücken Sie schließlich den Bedienknopf, um den manuellen Garvorgang zu starten.

3. Temperatur/Zeit-Verstellen

- Die Temperatur kann zwischen 40 °C und 200 °C verstellt werden. Die Zeit kann zwischen 0 und 24 Stunden verstellt werden.
- Die Temperatur wird bei jeder Drehung des Bedienknopfes um 5 °C verändert.
- Die Zeit wird bei jeder Drehung des Bedienknopfes um 1 Minute verändert. Drehen Sie den Bedienknopf die verstellte Zeit um 5 Sekunden zurück, um die Einstellung zu bestätigen und den Garvorgang zu starten.
- Die Temperatur und Zeit können während des Garvorgangs angepasst werden, ohne dass der aktuelle Garmodus beeinflusst wird. Der Bedienknopf bestätigt die neuen Einstellungen, und der Garvorgang wird auf der Grundlage dieser aktualisierten Parameter fortgesetzt.
- Wenn der Korb während des Garvorgangs herausgezogen wurde, ohne dass die Einstellungen bestätigt wurden, wird der Garvorgang nach Wiedereinsetzen des Korbes fortgesetzt. Wenn der Korb mehr als 10 Sekunden herausgezogen wird, wird der aktuelle Garvorgang abgebrochen.
- Wenn der Korb nach der Mitte/Ende während des Garens geöffnet wird.

4. Warmhalte-Funktion

- Die Warmhalte-Funktion ist standardmäßig aktiviert. Diese Funktion kann aktiviert oder deaktiviert werden, indem Sie zu Einstellungen > Thermostatsteuerung navigieren und den Bedienknopf auf dem Display drücken. Um die Warmhaltefunktion zu deaktivieren, nachdem Sie das Display 1 Sekunde lang gedrückt halten, wobei die Funktion und die Timer auf dem Bildschirm angezeigt werden.
- Die Warmhaltefunktion ist auf 30 Minuten bei einer Temperatur von 80 °C eingestellt. Wenn der Korb der Heißluft-Fritteuse während der Warmhaltefunktion herausgezogen wird, wird sowohl die Funktion als auch der Timer stoppen und fortsetzen, sobald der Korb wieder eingeschoben wird. Die Warmhaltefunktion wird automatisch ausgeschaltet, wenn die Heißluft-Fritteuse angehoben wird. Wenn die Heißluft-Fritteuse nicht innerhalb von 1 Minute ausgeschaltet wird, wird die Funktion beendet und der Bildschirm kehrt zum Startbildschirm des entsprechenden Rezepts zurück.
- Die Warmhaltefunktion wird nach dem Kochen automatisch aktiviert. Die Heißluft-Fritteuse wird alle 1 Minute einen Piepton ertönen lassen, um Sie daran zu erinnern, das Essen zu entfernen. Die Warmhaltefunktion wird beendet, wenn der Korb entfernt oder die Heißluft-Fritteuse angehoben wird. Es ertönt jedoch ein weiterer Piepton, um Sie daran zu erinnern, das Essen zu entfernen.
- Die Warmhaltefunktion wird in den Modi Joghurt, Getrocknetes Obst und Aufbacken nicht unterstützt.

Reinigung und Wartung

Ziehen Sie den Stecker des Stromkabels ab, bevor Sie die Heißluft-Fritteuse reinigen und warten, und warten Sie, bis sie ausreichend abgekühlt ist, bevor Sie fortfahren. Entfernen Sie den Korb aus der Heißluft-Fritteuse, wenn Sie die Heißluft-Fritteuse reinigen.
- Oberfläche der Heißluft-Fritteuse:
Wischen Sie die Oberfläche der Heißluft-Fritteuse kann mit einem trockenen, weichen Tuch oder einem mit einem neutralen Reinigungsmittel angefeuchteten Schwamm abgewischt werden.
- Innenraum:
Um hartnäckige Flecken im Innenraum der Heißluft-Fritteuse zu entfernen, tragen Sie eine geeignete Menge Reinigungsmittel auf ein feuchtes Tuch oder einen Schwamm auf und wischen den Innenraum sauber. Falls Flecken bestehen bleiben, verwenden Sie einen weichen, mit Wasser angefeuchteten Schwamm, um die Reinigungsmittelreste zu entfernen.
- Korb:
Reinigen Sie die Heißluft-Fritteuse nach jedem Gebrauch. Der Korb der Heißluft-Fritteu