


NOVA 49"



WARNINGS

POWER

- Only use the power unit provided to power the device.
- Check mains rating before plugging the power unit in.
- Do not pull on the cable to unplug the device.
- Turn Off the device before unplugging.

SAFETY PRECAUTIONS

- Keep the device away from rain and humidity to prevent risk of fire and electrocution.
- Do not introduce material (solid or liquid) inside. If this should accidentally occur, disconnect the device from power and have it inspected by qualified personnel.
- Keep the device away from children, to prevent accidental damage.
- Do not touch the device with wet hands to prevent electrical shock or mechanical damage.
- Do not use the device if it should fall or the external casing is damaged. Risk of electrocution if the device is used in such conditions.
- It is advisable to disconnect the device from power if the monitor is not used for a certain time.
- Never open the device. In all cases, contact Arozzi for repairs.

INSTALLATION PRECAUTIONS

- To prevent the device from overheating, arrange it in a position that allows the flow of air to enter through the slots in the casing.
- Do not install near sources of heat, such as radiators or hot air ducts.
- Slots and openings in the cabinet are provided for ventilation. These openings must not be blocked or covered: risk of fire, electrocution and mechanical failure.
- Keep away from direct sunlight.
- Do not use the device in presence of smoke, vapor, humidity, dust or intense vibrations.
- Do not install this device on an unstable surface, such as a wobbly or slanted table. The device could fall causing injury or mechanical failures.
- Do not install the device in a place where it could be exposed to humidity or water.
- Do not direct a jet of water onto the device: risk of fire, electrocution or mechanical failure.
- Stop using the device if water or other material should penetrate inside: risk of fire and electrocution.
- Do not place heavy or heat-generating objects on top of the device: this could damage the casing and/or increase internal temperature causing faults.
- Keep magnets and magnetized objects away from the device to prevent faults.
- Wait for a while before operating a device after transporting it from a cold place to a warm place and vice versa. Wait on average for about three hours: this will allow the device to adapt to the new ambient (temperature, humidity, etc.).

The monitor is provided with a metal base and rubber feet. It can be positioned on a horizontal surface, such as a desk or a table. Make sure that the device is fastened firmly and that it is not resting on unstable supports or surfaces. Dropping could cause severe injury and damage the device.

Remember to adjust the brightness and contrast to obtain a perfect image.

CLEANING THE DEVICE

Use a dry cloth to remove dust and dirt. Dip the cloth in neutral detergent if dirt cannot be eliminated with a dry cloth alone. Do not use volatile liquids (such as petrol, alcohol, solvents, etc.) or chemically treated clothes to clean the device to prevent deformation, deterioration or scratches to the paint finish.

PRIVACY AND COPYRIGHT

This monitor is a device for Gaming, Content creation or Media consumption.

Recording of images is subject to the laws in force in your country.

Recording of images protected by copyright is forbidden.

Product users shall be responsible for checking and respecting all local rules and regulations concerning monitoring and recording video signals. The manufacturer SHALL NOT BE LIABLE for use of this product not in compliance with the laws in force.



youtube.com/@ArozziSupport




EU: arozzi.se/support/
US: arozzi.com/support/
Elsewhere: arozzi.se/support/

PACKING LIST




Monitor




Stand




Screws



User Manual




**Power Adapter and
Power Cable**



**USB-C and
DisplayPort Cable**

MONITOR INPUTS



1

2

3

4


5

6

7

8

9




Warning: Always use the appropriate power cord.


- 1 Power (DC 24V, 6.25A)
- 2 HDMI1 (Support DQHD 165Hz, HDR, AdaptiveSync, OD, MPRT)
- 3 HDMI2 (Support DQHD 165Hz, HDR, AdaptiveSync, OD, MPRT)
- 4 DP (Support DQHD 165Hz, HDR, AdaptiveSync, OD, MPRT)
- 5 USB-C (Support DQHD 120Hz, HDR, AdaptiveSync, OD, MPRT, 65W Power Delivery, USB awake) (USB 3.0)
- 6 USB-B (Data + USB awake) (USB 2.0)
- 7 USB-A (Data + Peripherals) (USB 2.0)
- 8 USB-A (Data + Peripherals) (USB 2.0)
- 9 Audio Out

ASSEMBLY WITH STAND


1




2



3




4



Keep the monitor on a protective surface until it's been fully assembled.

CONTROL PANEL




Monitor Button	Action
 Push	Power ON the monitor / Enter mini menu if the monitor is already turned on / Enter or confirm the selected menu item in the OSD.
 Left	Go left in the OSD menu / Select signal source when OSD is not active.
 Right	Go right in the OSD menu / Change brightness when OSD is not active.
 Up	Go up in the OSD menu / Select scenario mode menu when OSD is not active.
 Down	Go down in the OSD menu / turn on the crosshair function when OSD is not active.

MINI MENU


Push the joystick to access the mini menu. There are four choices here.

- Go down and push the joystick to power OFF the monitor.
- Go left and push the joystick to enter the input source menu.
- Go up and push the joystick to access the first saved shortcut key / hotkey menu
- Go right and push the joystick to enter the main OSD menu.




INITIAL SETUP

- Connect the monitor to a power outlet. Check mains rating before plugging the power unit in.
- Press the joystick on the bottom of the monitor to turn it on.
- Connect the input cable to the corresponding input on the monitor. The source is automatically detected.
- To change between inputs, push the joystick on the bottom of the monitor to the left. Then push up or down to choose the input source between HDMI1, HDMI2, DP and USB-C.
- If the monitor cannot find a signal on the chosen input, it will auto-select the input where a signal is present.




OSD MENU

Input Source



Input Source Switch the signal input to USB-C / DP / HDMI1 / HDMI2.
No signal results in auto-select.

Brightness / Contrast



Brightness Change the Brightness value from 0 to 100.
Contrast Change the Contrast value from 0 to 100.
DCR Dynamic Contrast Ratio. Automatically adjusts screen brightness depending on the content shown.

Color Settings

DP		Resolution: 5120x1440@165Hz
Input Source	Gamma	2.2
Brightness/Contrast	Picture Mode	Standard
Color Settings	Color Temperature	Normal
Picture Quality Settings	Hue	50
Display	Saturation	50
Audio	Low Blue Light	0
Multi-Window		
OSD		
Other		
		Window1: InputSource: DP Resolution: 5120x1440@165Hz
		Window2: InputSource: Resolution:

- Gamma** Change the display Gamma value to: 1.8, 2.0, 2.2, 2.4, 2.6.
- Picture Mode** Change the Picture Mode to: Standard, Photo, Movie, Game, FPS, RTS.
- Color Temperature** Change the Color Temperature to: Normal, Warm, Cool, User.
- Hue** Change the display Hue value from 0 to 100.
- Saturation** Change the display Saturation value from 0 to 100.
- Low Blue Light** Reduce blue light to make the image warmer and more pleasing to the eyes.

Picture Quality Settings

DP		Resolution: 5120x1440@165Hz
Input Source	Sharpness	50
Brightness/Contrast	Response Time	Off
Color Settings		
Picture Quality Settings		
Display		
Audio		
Multi-Window		
OSD		
Other		
		Window1: InputSource: DP Resolution: 5120x1440@165Hz
		Window2: InputSource: Resolution:

- Sharpness** Change the display Sharpness value from 0 to 100.
- Response Time** Also called OverDrive. Changes pixel response times.

Display

DP		Resolution: 5120x1440@165Hz
Input Source	Aspect Ratio	Wide Screen
Brightness/Contrast		
Color Settings		
Picture Quality Settings		
Display		
Audio		
Multi-Window		
OSD		
Other		
	Window1: InputSource: DP Resolution: 5120x1440@165Hz	Window2: InputSource: Resolution:

Aspect RatioChange the image Aspect Ratio to Wide Screen, Auto, 4:3, or 1:1.

Audio

DP		Resolution: 5120x1440@165Hz
Input Source	Mute	Off
Brightness/Contrast	Volume	50
Color Settings	Audio Source	Auto Source
Picture Quality Settings		
Display		
Audio		
Multi-Window		
OSD		
Other		
	Window1: InputSource: DP Resolution: 5120x1440@165Hz	Window2: InputSource: Resolution:

- Mute** Turn On or Off to mute the audio source.
- Volume** Change the audio source volume from 0 to 100.
- Audio Source** Change audio input between USB-C / DP / HDMI1 / HDMI2 when using PIP. No selection results in Auto Source.

Multi-Window

DP		Resolution: 5120x1440@165Hz
Input Source	Multi-Window	Off
Brightness/Contrast	Sub Win2 Input	DP
Color Settings	PIP Size	Medium
Picture Quality Settings	PIP Position	Top Right
Display	Swap	
Audio		
Multi-Window		
OSD		
Other		
		Window1: InputSource: DP Resolution: 5120x1440@165Hz
		Window2: InputSource: Resolution:

- Multi-Window** Select which multi-window type to use:
 Off.
 PIP (Picture in picture: Small window in the corner showing a secondary input).
 PBP (Picture by picture: Half the screen will be used for each input).
- Sub Win2 Input** Select the PIP input source: USB-C / DP / HDMI1 / HDMI2.
- PIP Size** Set the PIP size to Small / Medium / Large.
- PIP Position** Set the PIP Position to Top Right / Top Left / Bottom Left / Bottom Right / Mid.
- Swap** Switch the two input source positions.

OSD

DP		Resolution: 5120x1440@165Hz
Input Source	Language	English
Brightness/Contrast	OSD H-Position	50
Color Settings	OSD V-Position	50
Picture Quality Settings	OSD Transparency	20
Display	OSD Time Out	10
Audio	OSD Rotation	Normal
Multi-Window		
OSD		
Other		
		Window1: InputSource: DP Resolution: 5120x1440@165Hz
		Window2: InputSource: Resolution:

- Language** Change the OSD Menu display language.
- OSD H-Position** Change the horizontal position of the OSD Menu.
- OSD V-Position** Change the vertical position of the OSD Menu.
- OSD Transparency** Change the transparency value of the OSD Menu from 0 to 100.
- OSD Time Out** Change how long the OSD Menu is on before it automatically exits.
- OSD Rotation** Rotate the OSD Menu.

Other

DP		Resolution: 5120x1440@165Hz
Input Source	FreeSync (Adaptive Sync)	Off
Brightness/Contrast	HDR	Off
Color Settings	MPRT	Off
Picture Quality Settings	KVM	Auto Detect
Display	USB Update FW	
Audio	Flicker Free	On
Multi-Window	Light Effect	On
OSD	Reset	
Other		
		Window1: InputSource: DP Resolution: 5120x1440@165Hz Window2: InputSource: Resolution:

Adaptive Sync	Matches the monitor refresh rate to the graphics card framerate.
HDR	High Dynamic Range. HDR must also be enabled on the PC operating system.
MPRT	Reduces motion blur. This will disable full brightness.
KVM	Change the image KVM to USB-B / Type-C / Auto Detect. See more below.
USB Update FW	Run firmware update from USB
Flicker Free	Reduces flickering to reduce eye strain
Light Effect	Control the RGB ring on the back of the monitor. Multicolor fade On / Off.
Reset	Restore the monitor to factory settings.

KVM FEATURE

KVM (Keyboard Video Mouse) allows you to connect two computers to the monitor while keeping your keyboard and mouse automatically connected to the selected input source PC.

Connections

- Connect one PC using the USB-C port
- Connect the other PC using HDMI/DP and the USB-B port
- Connect your keyboard and mouse to the USB-A ports

How to use

- Set KVM to Auto Detect in the OSD menu (see “Other Features” above).
- Select your secondary input source (HDMI/DP/USB-C) in the Input Source menu.
- Your keyboard and mouse will now work with the selected input source PC.

USB HUB

To use the built-in USB hub, connect the PC using one of the two following methods:

- Using a USB-C cable.
- Using HDMI / DP and the USB-B port.

You can now use the USB-A ports on the monitor as a USB hub.

SPECIFICATIONS

Display

Screen Size	49"
Panel Type	VA
Curvature	R1500
Backlight Type	LED
Aspect Ratio	32 : 9
Brightness (Max.)	350 cd/m²
Contrast Ratio (Max.)	3000 : 1
Resolution	5120X1440 @ 165Hz
Response Time (Max.)	MPRT 1ms
Color Gamut	100% sRGB / 90% DCI-P3
Viewing Angle (Horizontal/Vertical)	178°/178° (CR>10)
Color Support	16.7 M Colors (8bit + FRC)

Connections

DP (1.4)	x1 (DQHD @ 165Hz)
HDMI (2.1)	x2 (DQHD @ 165Hz)
USB-C (3.0)	x1 (Video and data) (DQHD @ 120Hz)
USB-B (2.0)	x1 (Data input)
USB-A (2.0)	x2 (Data output)
Audio Out 3.5mm	x1

Power

Power Consumption	Max 75W
Stand By Power (DPMS)	<0.5W
Type	DC24V, 6.25A
USB-C Power Delivery	65W

FEATURES

Tilt	+5° to -15°
Swivel	+45° to -45°
Height Adjustable Stand	7,5 - 18,5cm / 3" - 7.3"
HDR	Supported
Adaptive Sync	Supported (From 48 - 165Hz)
RGB Light	Multicolor fade on / off
Cabinet Color	Black / White / Pink / Forest Green
Over Drive	Supported
Flicker Free	Supported
Low Blue Light Mode	Supported
VESA mount	75x75 mm / 100x100 mm
Speakers	Built-in (2x3W)