

Safety Instructions and Warnings
Sicherheitshinweise und Warnhinweise
Consignes de sécurité et avertissements
Advertencias de seguridad e advertencias
Istruzioni di sicurezza e avvertenze
Veiligheids- en waarschuwingaanswijzingen
Avisos de segurança e advertências
Biztonsági Figyelmeztetések
Sikkerheds- og Varselshenvisninger
Säkerhetsanvisningar och varningar
Turvallisuusohjeita ja varoituksia
Sikkerheds- og adværslingsanvisninger
Bezpečnostní pokyny a upozornění
Bezpečnostné a výstražné upozornenia
Güvenlik Önerileri ve Uyarılar

LEDLENSER GmbH & Co. KG, Kronenstr. 5-7, 42699 Solingen, Germany
Phone +49 212/5948-0 Fax +49 212/5948-20
safety@ledlenser.com
EN

Instructions regarding the product
This product must be used as a lamp.
Adhere to these instructions and the enclosed quick start guide without delay.
Do not swallow small parts and keep out of the reach of children.

Instructions regarding ambient conditions
The product may only be used in the temperature range from +20 to +40 °C.
The product must not be exposed to permanent direct sunlight, strong vibrations, high humidity and/or moisture, solvents and vapours or operated in explosive atmospheres.

Instructions for handling the product
Do not wear (head) bands, (hand) loops etc. around the neck.
Do not use the product as a tool. Risk of fire and burns. Light generates heat. Do not cover. Risk of heat injury.

Instructions regarding batteries
Caution! In light of the fact that batteries pose a potential risk, they must be kept out of the reach of children.
If the lamp or battery overheats, the charging function will temporarily be suspended.

Instructions regarding disposal
A sign on the crossed-out dustbin indicates the statutory obligation to dispose of such items separate from domestic waste.
On the one hand, devices and batteries contain valuable raw materials while on the other they may also contain harmful substances.

Instructions regarding maintenance/repairs
The product must not be modified and/or altered.
Repairs and maintenance may only be carried out by authorised specialists.
For customer service and further information, see www.ledlenser.com

Instructions regarding disposal
A sign on the crossed-out dustbin indicates the statutory obligation to dispose of such items separate from domestic waste.
On the one hand, devices and batteries contain valuable raw materials while on the other they may also contain harmful substances.

Instructions regarding disposal
A sign on the crossed-out dustbin indicates the statutory obligation to dispose of such items separate from domestic waste.
On the one hand, devices and batteries contain valuable raw materials while on the other they may also contain harmful substances.

Instructions regarding disposal
A sign on the crossed-out dustbin indicates the statutory obligation to dispose of such items separate from domestic waste.
On the one hand, devices and batteries contain valuable raw materials while on the other they may also contain harmful substances.

